

FOLLOW ME SETTINGS

With Follow Me, GPS Trackdown can automatically send your location to your designated contact at a frequency that you define (e.g. every 8 hours for 3 days while you are on vacation). The notices can be sent by Email or by SMS Text. Set it and forget it.

You can test your settings to make sure they are correct or disable this feature at any time.

1. Check to enable Follow Me
2. Select a Contact or enter an email address or mobile number
3. Select the interval
4. Select the duration
5. Select the method for sending (i.e. email or sms text)
6. Optionally test your settings
7. Select the check button to save your changes



FOLLOW ME SETTINGS

 Allow Follow Me

Check to allow your Follow Me contact to receive your location updates **1**

Send To

Enter **2** contact name for Follow Me

ICE

my_ice_contact@gmail.com

[\(202\) 777-8888](tel:(202)777-8888)

Follow Me Interval **3** 8 hours ▾

Follow Me For **4** 3 days ▾

Until 02/27 09:37 AM

Send By **5** EMAIL SMS

Choose a method for sending to your Follow Me contact



Your **Follow Me** contact has to option to turn off receiving your location notices by texting you the word *trackdown*.